

# ECOSMART WAREHOUSE - ONLINE LTD

*Personal Safety...Site Safety...Food Safety*  
**Anti-Slip Specialists**

## Liquid Rubber® DIY

Easy Waterproofing Solutions

### WATERPROOFING RETAINING WALLS

☎ 1300 2LR DIY  
[www.liquidrubberdiy.com](http://www.liquidrubberdiy.com)



Scan here to visit  
our website and  
order now!



#### STAGE 1: Water blasting

- Wash/waterblast the entire surface.
- Use a leaf blower to remove excess water.

#### Products required:

- LR DIY - Waterproof Sealant
- LR DIY - GEO Textile
- LR DIY - RapidCure Spray



#### STAGE 2: Detailing

- Once dry, apply LR DIY - Waterproof Sealant by brush, roller or spray machine to cracks, holes, gaps, corners and wall-floor joint.



- Apply the correct width LR DIY - GEO Textile at the same time onto the wet product over the hole, crack, seams etc and ensure you brush the air from underneath the applied GEO Textile and make sure there are no crinkles.
- Use LR DIY - RapidCure Spray to instantly set the product in case of approaching rain or to speed the job up.
- Allow curing for 24 hours before next step.

**Contact Us Now . . . ☎ 0800 009 ECO . . . [sales@ewo.co.nz](mailto:sales@ewo.co.nz)**



# ECOSMART WAREHOUSE - ONLINE LTD

*Personal Safety...Site Safety...Food Safety*  
**Anti-Slip Specialists**

## STAGE 3: First Coat

- Apply the first coat of LR DIY - Waterproof Sealant by brush, roller or spray machine over the entire wall.
- Use LR DIY - RapidCure Spray to instantly set the Waterproof Sealant in case of approaching rain or to speed the job up.
- Allow curing for 24 hours.

## Products required:

- LR DIY - Waterproof Sealant
- Graco - Airless Spray Machine
- LR DIY - RapidCure Spray



## STAGE 4: Second Coat

- Apply the second coat of LR DIY - Waterproof Sealant by brush, roller or spray machine over the entire wall.
- Use LR DIY - RapidCure Spray to instantly set the Waterproof Sealant in case of approaching rain or to speed the job up.
- Allow curing for 24 hours.

## Products required:

- Corflute

## STAGE 5: Corflute

- Let the Waterproof Sealant cure for 2-3 days before backfilling.
- The best practice is to put corflute between the Waterproof Sealant membrane and the soil to avoid the membrane being cut or punctured by a sharp stone in the soil.