

# ECOSMART WAREHOUSE - ONLINE LTD

*Personal Safety...Site Safety...Food Safety*  
**Anti-Slip Specialists**

## Liquid Rubber® DIY

Easy Waterproofing Solutions

### WATERPROOFING TANKS

☎ 1300 2LR DIY  
[www.liquidrubberdiy.com](http://www.liquidrubberdiy.com)



Scan here to visit  
our website and  
order now!

#### STAGE 1:

- Waterblast the entire surface.
- Wear protective gear (gumboots, face-mask, overall).
- Use a submersible pump to empty the tank and a wet and dry vacuum to suck the remaining water out.
- Put a fan-forced ventilator in to start the drying process and for air circulation.

#### STAGE 2: Detailing

- Apply LR DIY - Seam Tape over bigger holes or cracks directly.
- Apply LR DIY - Waterproof Sealant by brush, roller or spray machine to cracks, seams, holes, corners, pipe inlet/overflows or over the top of applied Seam Tape.

- Apply the correct width of LR DIY - GEO Textile at the same time onto the wet product over the holes, cracks, seams etc. and ensure you brush the air from underneath the applied GEO Textile and make sure there are no crinkles.
- Use LR DIY - RapidCure Spray to instantly set the Waterproof Sealant and to speed the job up.
- Allow curing for 24 hours before the next step.

#### Products required:

- LR DIY - Waterproof Sealant
- LR DIY - Seam Tape
- LR DIY - GEO Textile
- LR DIY - RapidCure Spray



**Contact Us Now . . . ☎ 0800 009 ECO . . . [sales@ewo.co.nz](mailto:sales@ewo.co.nz)**



# **ECOSMART WAREHOUSE - ONLINE LTD**

**Personal Safety...Site Safety...Food Safety**  
**Anti-Slip Specialists**

## **STAGE 3: First Coat - Waterproof Sealant**

- Apply the first coat of LR DIY - Waterproof Sealant by brush, roller or spray machine over the walls and floor-wall joints.
- Use LR DIY - RapidCure Spray to instantly set the Waterproof Sealant and to speed the job up.
- Allow curing for 24 hours.

### **Products required:**

- LR DIY - Waterproof Sealant
- LR DIY - RapidCure Spray
- Graco - Airless Spray Machine



## **STAGE 4: Second Coat - Waterproof Sealant**

- Apply the second coat of LR DIY - Waterproof Sealant by brush, roller or spray machine over the walls and floor-wall joints.
- Use LR DIY - RapidCure Spray to instantly set the Waterproof Sealant and to speed the job up.
- Allow curing for 24 hours.
- For best results and a long-lasting waterproof membrane, apply a third coat of LR DIY - Waterproof Sealant.

## **STAGE 5: Floor Coating**

- Apply a thick coat LR DIY - Waterproof Sealant to the floor and work your way toward the ladder overlapping the floor-wall joints.
- Climb out of the tank and use an extension on your roller to cover the area where the ladder was, making a total seamless membrane in your tank.
- Allow 10 Days for the product to cure with the fan continuously going (24/7) to dry out all the moisture.
- It is very important that the waterproof membrane is fully cured before filling the tank.

